

Tool Model	Part NO	Part Code	Description
EH-20F	6	YM01043	MOTOR RS-360SH-22130
EH-20F	7	EH13405	MOTOR GEAR
EH-20F	8	AA25115	SCREW 2.6X4
EH-20F	9	EH11841	MIDDLE GEAR 1
EH-20F	10	EH11842	MIDDLE GEAR 2
EH-20F	11	JJ10511	E-RING 3.2 CF
EH-20F	14	EH80068	LINK ASSY
EH-20F	18	EH11848	LATCHET LEVER
EH-20F	19	EH81053	BODY ASSY(EUR)
EH-20F	20	EH11850	PUSHER
EH-20F	21	KK23652	COMP. SPRING 3652
EH-20F	22	EH13212	STAPLE GUIDE
EH-20F	23	EH11852	EH14293 : FACE PLATE
EH-20F	24	EH11853	DRIVER
EH-20F	25	EH14241	FORMING PLATE
EH-20F	26	EH11855	GUIDE PLATE
EH-20F	29	EH11858	LATCHET
EH-20F	30	JJ10104	E-RING 2.3
EH-20F	31	EH11859	FEED PLATE
EH-20F	32	KK13227	SPRING 3227
EH-20F	33	EH12226	CENTER SHAFT
EH-20F	34	EH11861	FEED LEVER
EH-20F	35	JJ18102	E-RING 4
EH-20F	36	EH11862	DRIVE SHAFT
EH-20F	37	EH12225	DRIVER SHAFT
EH-20F	38	EH11864	DRIVER GEAR
EH-20F	39	EH11865	HOME POSITION SENSOR CAM
EH-20F	40	EH70185	MOTOR PWB UNIT(CF)
EH-20F	41	AA05534	PAN HEAD SCREW 2X10 FT
EH-20F	47	AA05501	TAP TIGHT M2X4
EH-20F	48	AA25213	BINDING SCREW 3X5
EH-20F	49	EH12231	DUMPER
EH-20F	50	EH12379	DUMPER COLLAR
EH-20F	51	EH12209	CLINCHER
EH-20F	52	EH14307	CLINCHER PLATE
EH-20F	53	EH12210	CLINCHER GUIDE
EH-20F	54	KK23583	COMP. SPRING 3583
EH-20F	55	EH13205	SLIDER
EH-20F	56	KK23008	SPRING 3008
EH-20F	57	EH12212	SUB LINK
EH-20F	58	EE39149	FLATE WASHER 149
EH-20F	60	EH12213	SWITCH HOLDER
EH-20F	61	EH70559	EH70699 : START SWITCH UNIT
EH-20F	62	EH12215	HARNESS UNIT
EH-20F	63	BB71111	BOLT 4X8
EH-20F	64	EH12216	SENSOR KNOB
EH-20F	65	EH70703	MAIN PWB UNIT
EH-20F	67	ZU10122	AC ADAPTER
EH-20F	68	EH12220	UNDER PLATE
EH-20F	69	EH13206	LOWER CASE
EH-20F	70	AA21552	PAN HEAD SCREW 4X12
EH-20F	71	EH12223	UPPER CASE
EH-20F	72	AA05102	TAP TIGHT (P)M3X8
EH-20F	73	EH12222	CASE CAP
EH-20F	74	AA21107	PAN-HEAD SCREW 3X8
EH-20F	75	YZ30001	CUSHION SJ-5012 BLACK
EH-20F	76	EH12227	CAUTION LABEL
EH-20F	77	EH12230	RUBBER
EH-20F	523	YU30213	FUSE 2373.15